

# Roadmap to Lecture 5

- ~~1. Governing equations of fluid dynamics~~
- ~~2. RANS equations – Reynolds averaging~~
- ~~3. The Boussinesq hypothesis~~
- ~~4. The gradient diffusion hypothesis~~
- 5. Sample turbulence models**

# Sample turbulence models

- It is important to know the specific version of the turbulence model that you are planning to use, as many turbulence models can have different variants.
- And each variant can have different range of applicability and limitations.
- Therefore, it is extremely recommended to read the original source of documentation of the model.
- This can be a paper or the help system of the CFD solver you are using.
- You do not do CFD and turbulence modeling without understanding the theoretical background.
- From now on, we will always mention the specific version of the turbulence model that we are going to use, and we will give some useful references.

# Sample turbulence models

## RANS equations – EVM equations

- By using the Boussinesq approximation in the incompressible RANS equations, we obtain the following set of equations using vector notation (**the solvable equations**),

$$\nabla \cdot (\bar{\mathbf{u}}) = 0$$

$$\frac{\partial \bar{\mathbf{u}}}{\partial t} + \nabla \cdot (\bar{\mathbf{u}}\bar{\mathbf{u}}) = -\frac{1}{\rho} \left( \nabla \bar{p} + \frac{2}{3} \rho \nabla k \right) + \nabla \cdot \left[ \frac{1}{\rho} (\mu + \mu_t) \nabla \bar{\mathbf{u}} \right]$$

- The problem now reduces to computing the turbulent eddy viscosity in the momentum equation.
- Let us explore two closure models, the  $k - \epsilon$  model and  $k - \omega$  the model.

# Sample turbulence models

## RANS equations – EVM equations

- By using the Boussinesq approximation in the incompressible RANS equations, we obtain the following set of equations using index notation (**the solvable equations**),

$$\frac{\partial \bar{u}_i}{\partial x_i} = 0$$
$$\frac{\partial \bar{u}_i}{\partial t} + \frac{\partial \bar{u}_i \bar{u}_j}{\partial x_j} = -\frac{1}{\rho} \left[ \frac{(\partial \bar{p} + \partial \frac{2}{3} \rho k)}{\partial x_i} \right] + \frac{\partial}{\partial x_j} \left[ \frac{1}{\rho} (\mu + \mu_t) \frac{\partial \bar{u}_i}{\partial x_j} \right]$$

- The problem now reduces to computing the turbulent eddy viscosity in the momentum equation.
- Let us explore two closure models, the  $k - \epsilon$  model and  $k - \omega$  the model.

# Sample turbulence models

- Standard  $k - \epsilon$  turbulence model by Launder and Sharma [1].

[1] B. E. Launder, B. I. Sharma. Application of the Energy-Dissipation Model of Turbulence to the Calculation of Flow Near a Spinning Disc. Letters in Heat and Mass Transfer. 1974.

# Sample turbulence models

## $k - \epsilon$ Turbulence model governing equations

- It is called  $k - \epsilon$  because it solves two additional equations for modeling the turbulent eddy viscosity, namely, the turbulent kinetic energy  $k$  and the turbulence dissipation rate  $\epsilon$ .

$$\nabla_t k + \nabla \cdot (\bar{\mathbf{u}}k) = \tau^R : \nabla \bar{\mathbf{u}} - \epsilon + \nabla \cdot \left[ \left( \nu + \frac{\nu_t}{\sigma_k} \right) \nabla k \right]$$

$$\nabla_t \epsilon + \nabla \cdot (\bar{\mathbf{u}}\epsilon) = C_{\epsilon_1} \frac{\epsilon}{k} \tau^R : \nabla \bar{\mathbf{u}} - C_{\epsilon_2} \frac{\epsilon^2}{k} + \nabla \cdot \left[ \left( \nu + \frac{\nu_t}{\sigma_\epsilon} \right) \nabla \epsilon \right]$$

- With the following closure coefficients,

$$C_{\epsilon_1} = 1.44 \quad C_{\epsilon_2} = 1.92 \quad C_\mu = 0.09 \quad \sigma_k = 1.0 \quad \sigma_\epsilon = 1.3$$

- And the following closure relationships,

$$\nu_t = \frac{C_\mu k^2}{\epsilon} \quad \omega = \frac{\epsilon}{C_\mu k} \quad l = \frac{C_\mu k^{3/2}}{\epsilon}$$

# Sample turbulence models

## $k - \epsilon$ Turbulence model governing equations

- The closure equations correspond to the standard  $k - \epsilon$  model.
- They have been manipulated so there are no terms including fluctuating quantities (*i.e.*, velocity and pressure), and double or triple correlations of the fluctuating quantities.
- The Reynolds stress tensor is modeled using the Boussinesq approximation.
- The turbulence dissipation rate is modeled using a second transport equation.

$$\begin{aligned}
 \nabla_t k + \nabla \cdot (\bar{\mathbf{u}}k) &= \overbrace{\tau^R : \nabla \bar{\mathbf{u}}}^{\text{Production}} - \epsilon + \nabla \cdot \left[ \left( \nu + \frac{\nu_t}{\sigma_k} \right) \nabla k \right] \\
 \nabla_t \epsilon + \nabla \cdot (\bar{\mathbf{u}}\epsilon) &= C_{\epsilon_1} \frac{\epsilon}{k} \overbrace{\tau^R : \nabla \bar{\mathbf{u}}}^{\text{Production}} - C_{\epsilon_2} \frac{\epsilon^2}{k} + \nabla \cdot \left[ \left( \nu + \frac{\nu_t}{\sigma_\epsilon} \right) \nabla \epsilon \right]
 \end{aligned}$$

Dissipation
Diffusion

Production
Diffusion

Production
Diffusion

Dissipation

# Sample turbulence models

- Wilcox (1988)  $k - \omega$  turbulence model by Wilcox [1, 2].

[1] D. C. Wilcox. Reassessment of the Scale-Determining Equation for Advanced Turbulence Models. AIAA Journal, 1988.

[2] D. C. Wilcox. Turbulence Modeling for CFD. DCW Industries, 2010.



# Sample turbulence models

## $k - \omega$ Turbulence model governing equations

- It is called  $k - \omega$  because it solves two additional equations for modeling the turbulent viscosity, namely, the turbulent kinetic energy  $k$  and the turbulence specific dissipation rate  $\omega$ .

$$\nabla_t k + \nabla \cdot (\bar{\mathbf{u}}k) = \tau^R : \nabla \bar{\mathbf{u}} - \beta^* k \omega + \nabla \cdot [(\nu + \sigma^* \nu_t) \nabla k]$$

$$\nabla_t \omega + \nabla \cdot (\bar{\mathbf{u}}\omega) = \alpha \frac{\omega}{k} \tau^R : \nabla \bar{\mathbf{u}} - \beta \omega^2 + \nabla \cdot [(\nu + \sigma \nu_t) \nabla \omega]$$

- With the following closure coefficients,

$$\alpha = 5/9 \quad \beta = 3/40 \quad \beta^* = 9/100 \quad \sigma = 1/2 \quad \sigma^* = 1/2$$

- And the following closure relationships,

$$\nu_t = \frac{k}{\omega} \quad \epsilon = \beta^* \omega k \quad l = \frac{k^{1/2}}{\omega}$$

# Sample turbulence models

## $k - \omega$ Turbulence model governing equations

- The closure equations correspond to the Wilcox (1988)  $k - \omega$  model.
- They have been manipulated so there are no terms including fluctuating quantities (*i.e.*, velocity and pressure), and double or triple correlations of the fluctuating quantities.
- The Reynolds stress tensor is modeled using the Boussinesq approximation.

The diagram illustrates the governing equations for the  $k - \omega$  turbulence model. It shows two equations, one for  $k$  and one for  $\omega$ , with terms grouped into Production, Diffusion, and Dissipation. Red arrows indicate the flow of terms between the two equations.

$$\nabla_t k + \nabla \cdot (\bar{\mathbf{u}}k) = \underbrace{\tau^R : \nabla \bar{\mathbf{u}}}_{\text{Production}} - \underbrace{\beta^* k \omega}_{\text{Dissipation}} + \underbrace{\nabla \cdot [(\nu + \sigma^* \nu_t) \nabla k]}_{\text{Diffusion}}$$

$$\nabla_t \omega + \nabla \cdot (\bar{\mathbf{u}}\omega) = \underbrace{\alpha \frac{\omega}{k} \tau^R : \nabla \bar{\mathbf{u}}}_{\text{Production}} - \underbrace{\beta \omega^2}_{\text{Dissipation}} + \underbrace{\nabla \cdot [(\nu + \sigma \nu_t) \nabla \omega]}_{\text{Diffusion}}$$

The diagram shows that the Dissipation term in the  $k$  equation is  $\beta^* k \omega$ , and the Dissipation term in the  $\omega$  equation is  $\beta \omega^2$ . A red arrow points from the Dissipation term in the  $k$  equation to the Dissipation term in the  $\omega$  equation, indicating that  $\beta^* k \omega$  is equal to  $\beta \omega^2$ .

Sample turbulence models – Final remarks

# Sample turbulence models

## Final remarks

- The previous family of EVM models are probably the most widely used ones.
- The standard  $k - \epsilon$  turbulence model is a wall modeling (high Reynolds number model), and the  $k - \omega$  turbulence model (Wilcox 1998) is  $y^+$  insensitive (low-high Reynolds number).
- By inspecting the closure equations of the  $k - \epsilon$  model, we can evidence that the turbulent kinetic energy  $k$  and the turbulent dissipation rate  $\epsilon$  must go to zero at the correct rate in order to avoid turbulent viscosity production close to walls.

$$\nabla_t k + \nabla \cdot (\bar{\mathbf{u}}k) = \tau^R : \nabla \bar{\mathbf{u}} - \epsilon + \nabla \cdot \left[ \left( \nu + \frac{\nu_t}{\sigma_k} \right) \nabla k \right]$$

$$\nabla_t \epsilon + \nabla \cdot (\bar{\mathbf{u}}\epsilon) = C_{\epsilon_1} \frac{\epsilon}{k} \tau^R : \nabla \bar{\mathbf{u}} - C_{\epsilon_2} \frac{\epsilon^2}{k} + \nabla \cdot \left[ \left( \nu + \frac{\nu_t}{\sigma_\epsilon} \right) \nabla \epsilon \right]$$

$$\nu_t = \frac{C_\mu k^2}{\epsilon}$$


# Sample turbulence models

## Final remarks

- Instead, the  $k - \omega$  model does not suffer of this problem as the turbulence specific dissipation rate  $\omega$  is proportional to  $\omega \propto y^{-2}$ .
- Therefore, the specific dissipation rate  $\omega$  close to the walls is usually a large value.

$$\begin{aligned}\nabla_t k + \nabla \cdot (\bar{\mathbf{u}}k) &= \tau^R : \nabla \bar{\mathbf{u}} - \beta^* k \omega + \nabla \cdot [(\nu + \sigma^* \nu_t) \nabla k] \\ \nabla_t \omega + \nabla \cdot (\bar{\mathbf{u}}\omega) &= \alpha \frac{\omega}{k} \tau^R : \nabla \bar{\mathbf{u}} - \beta \omega^2 + \nabla \cdot [(\nu + \sigma \nu_t) \nabla \omega] \\ \nu_t &= \frac{k}{\omega}\end{aligned}$$

$$\omega = \frac{6\nu}{\beta_0 d^2} \quad \beta_0 \approx 0.075$$

 d is the distance to the first cell center normal to the wall (y)

- We will talk more about closure models in Lecture 6.

# Sample turbulence models

## Final remarks

- Remember, you need to define initial conditions and boundary conditions for all transported quantities when using turbulence models, including the turbulent variables.
- Also, you need to define the boundary conditions at the walls, not necessarily they are zero.
- No need to say that the boundary and initial values need to be physically realistic.
- For example, if you set the turbulent dissipation rate  $\epsilon$  or the specific dissipation rate  $\omega$  to zero, you will have convergence problems.
- Recall that in the  $k - \epsilon$  and  $k - \omega$  family of turbulence models the turbulent eddy viscosity is computed as follows,

$$\nu_t = \frac{k}{\omega} \qquad \nu_t = \frac{C_\mu k^2}{\epsilon}$$

- By the way, some models can be very sensitive to initial conditions.
- We addressed turbulence estimates in Lecture 4.
- We will revisit this subject, including wall values\*, in the next lectures.

\* The following site is an excellent reference for turbulence models in general, <https://turbmodels.larc.nasa.gov/>

# Sample turbulence models

## Short description of some RANS turbulence models

Model	Short description
<b>Spalart-Allmaras</b>	This is a one equation model. Suitable for external aerodynamics, turbomachinery and high-speed flows. Good for mildly complex external/internal flows and boundary layer flows under pressure gradient (e.g., airfoils, wings, airplane fuselages, ship hulls). Performs poorly with flows with strong separation.
<b>Standard k-epsilon</b>	This is a two-equation model. Very robust and widely used despite the known limitations of the model. Performs poorly for complex flows involving severe pressure gradient, separation, strong streamline curvature. Suitable for initial iterations, initial screening of alternative designs, and parametric studies. Can only be used with wall functions.
<b>Realizable k-epsilon</b>	This is a two-equation model. Suitable for complex shear flows involving rapid strain, moderate swirl, vortices, and locally transitional flows (e.g., boundary layer separation, massive separation, and vortex shedding behind bluff bodies, stall in wide-angle diffusers, room ventilation). It overcomes the limitations of the standard k-epsilon model.
<b>Standard k-omega</b>	This is a two-equation model. Superior performance for wall-bounded boundary layer, free shear, and low Reynolds number flows compared to models from the k-epsilon family. Suitable for complex boundary layer flows under adverse pressure gradient and separation (external aerodynamics and turbomachinery).
<b>SST k-omega</b>	This is a two-equation model. Offers similar benefits as the standard k-omega. Not overly sensitive to inlet boundary conditions like the standard k-omega. Provides more accurate prediction of flow separation than other RANS models. Can be used with and without wall functions. Probably the most widely used RANS model.